

AW-SF100 AUTO TRACKING SOFTWARE KEYBOARD SHORTCUTS

CAMERA PRESETS

KEY	FUNCTION
F1	Preset 1
F2	Preset 2
F3	Preset 3
F4	Preset 4
F5	Preset 5
F6	Preset 6
F7	Preset 7
F8	Preset 8
F9	Preset 9

CAMERA PAN / TILT CONTROL

KEY	FUNCTION
↑	Tilt Up
↓	Tilt Down
←	Pan Left
→	Pan Right
↑ + →	Diagonal Up / Right
→ + ↓	Diagonal Down / Right
↓ + ←	Diagonal Up / Left
← + ↑	Diagonal Down / Left
Shift + ↑	Fast Tilt Up
Shift + ↓	Fast Tilt Down
Shift + ←	Fast Left Pan
Shift + →	Fast Right Pan
Shift + ↑ + →	Fast Diagonal Up / Right
Shift + → + ↓	Fast Diagonal Down / Right
Shift + ↓ + ←	Fast Diagonal Up / Left
Shift + ← + ↑	Fast Diagonal Down / Left

CAMERA ZOOM CONTROL

KEY	FUNCTION
Shift + T	Zoom In (Tele)
Shift + W	Zoom Out (Wide)

AUTO TRACKING CONTROL

KEY	FUNCTION
Shift + S	Start / Stop Auto Tracking
Ctrl	Pause Auto Tracking