

CLEANING AND SANITIZING PANASONIC TOUGHBOOK DEVICES

APPLICATION AND TEST PROCEDURES











To keep your TOUGHBOOK® computer running for as long as possible, Panasonic rigorously tested these devices against prolonged use of disinfectant wipes. The test procedure was to wipe several areas on the outside of the device applying a pressure of 1 kgf/cm² with each disinfectant wipe listed on the below table for 10,000 times.

RECOMMENDATIONS

Panasonic recommends disinfectant wipes to avoid the risk of chemicals that can cause paint discoloration, and break down the rubber that seals the devices. When disinfecting with a spray, it is recommended that the disinfectant be sprayed onto a soft cloth (not sprayed directly onto the PC) and then dried.

Please use the guidelines presented in your Panasonic user manual for the proper cleaning procedures. And also be sure to refer to the warnings and instructions for proper usage on the disinfectant.

Panasonic is committed to providing the most durable and reliable mobile computing solutions. Panasonic cannot warranty the impact using the disinfectants over prolonged use or excessive exposure. Although these disinfectants are tested for our products, Panasonic does not endorse or advertise a particular brand of disinfectant and cannot warranty their effectiveness.

TEST RESULTS											
	Panasonic	55	31	33	20	G1	M1	A3	L1	N1	T1
Sani-Cloth® Plus Germicidal Disposal Cloth	Tested	Tested	Tested	Tested	Tested	Tested	Tested	Tested	Tested	Tested	Tested
Alcohol Prep Swabs	Tested	Tested	Tested	Tested	Tested	Tested	Tested	Tested	Tested	Tested	Tested
CaviWipes™	Tested	Tested	Tested	Tested	Tested	Tested	Tested	Tested	Tested	Tested	Tested
Total Solutions™ Disinfectant Wipes	Tested	Tested	Tested	Tested	Tested	Tested	Tested	Tested	Tested	Tested	Tested
Clorox Healthcare® Bleach Germicidal Wipes	Tested	-	Tested	Tested	Tested	Tested	Tested	Tested	Tested	Tested	Tested